

RocketRAID 26xx Controller FreeBSD Installation Guide

Version 1.0

Copyright © HighPoint Technologies, Inc.

All rights reserved.

Last updated on Apr 2, 2008

Table of Contents

1 Overview	1
2 Installing FreeBSD on RocketRAID 26xx Controller	1
Step 1 Prepare Your Hardware for Installation.....	1
Step 2 Check System BIOS Settings.....	1
Step 3 Prepare the Driver Diskette.....	1
Step 4 Install FreeBSD.....	2
3 Installing RR26xx Driver on an Existing System	4
Step 1 Copy the Driver Module	4
Step 2 Test the Driver Module	5
Step 3 Configure System to Automatically Load the Driver.....	5
Step 4 Configure System to Mount Volumes when Startup	6
4 Updating the Driver	6
5 Installing RAID Management Software.....	6
6 Uninstalling.....	6

1 Overview

The purpose of this document is to provide clear instructions on how to install and use RocketRAID 26xx Controller on a FreeBSD system.

2 Installing FreeBSD on RocketRAID 26xx Controller

If you would like to install FreeBSD onto drives attached to RocketRAID 26xx controller, please perform the following operations:

Step 1 Prepare Your Hardware for Installation

After you attach your hard disks to RR26xx controller, you can use RR26xx BIOS Setting Utility to configure your hard disks as RAID arrays, or just use them as single disks.

Note

If you have other SCSI adapters installed, you must make sure the RR26xx controller BIOS will be loaded firstly. If not, try to move it to another PCI slot. Otherwise you may be unable to boot up your system.

Step 2 Check System BIOS Settings

In your system BIOS SETUP menu, change **Boot Sequence** in such a way that the system will first boot from CDROM, next from and then from floppy drive, and then from SCSI. Refer to your BIOS manual to see how to set boot sequence.

If your BIOS settings do not support such a boot sequence, you can first set it to boot from CDROM. After you finish installation, set SCSI as the first boot device to boot up the system.

Step 3 Prepare the Driver Diskette

If you are installing FreeBSD, you must prepare a driver disk for RR26xx before installation.

First obtain the driver diskette image file, freebsd.img.

On a DOS or Windows system, you can make the boot diskette using rawrite.exe. It can be found on the FreeBSD CD (under \tools). Just run it under a command window and follow its prompt.

On a FreeBSD system, you can use the “dd” command to make the driver diskette. For example, Insert a floppy disk into the floppy drive and type the following command if you are installing FreeBSD 7.0 versions:

```
# dd if=freebsd_7.0.img of=/dev/fd0
```

Step 4 Install FreeBSD

- 1) Start installing the FreeBSD by booting from installation CD.
- 2) If you are installing FreeBSD 5.0 or earlier versions, skip this step. When “**Welcome to FreeBSD**” screen appears, select “**6**”.
- 3) When “**Hit [enter] to boot immediately or any other key for command prompt**” screen appears, press SPACE key to stop loader from autobooting.

```
BTX loader 1.00  BTX version is 1.01
Console: internal video/keyboard
BIOS driver A: is disk0
BIOS driver B: is disk1
BIOS driver C: is disk2
BIOS 636kB/74512kB available memory

FreeBSD/i386 bootstrap loader, Revision 0.8
(mailto:jkh@narf.osd.bsdi.com, Sat Apr 21 08:46:19 GMT 2001)
-
Hit [Enter] to boot immediately, or any other key for command prompt.
Booting [kernel] in 9 seconds...
```

<-press SPACE key

A prompted label "ok" will appear at the bottom of the screen.

- 4) Insert RR26xx driver diskette into floppy drive now. Type in "**load diskx:rr26xx-x.x**" (without quotation mark) and then press **enter**.

```
for FreeBSD 4.3-RELEASE
ok load kernel
ok load disk1:rr26xx-4.3.ko

for FreeBSD 4.4-RELEASE
ok load kernel
ok load disk1:rr26xx-4.4.ko

for FreeBSD 4.5-RELEASE
ok load disk1:rr26xx-4.5.ko

for FreeBSD 4.6.2-RELEASE
ok load disk1:rr26xx-4.6.2.ko

for FreeBSD 4.7-RELEASE
ok load disk1:rr26xx-4.7.ko

for FreeBSD 4.8-RELEASE
ok load disk1:rr26xx-4.8.ko

for FreeBSD 4.9-RELEASE
ok load disk1:rr26xx-4.9.ko

for FreeBSD 4.10-RELEASE
ok load disk1:rr26xx-4.10.ko

for FreeBSD 4.11-RELEASE
ok load disk1:rr26xx-4.11.ko

for FreeBSD 5.0-RELEASE
ok load disk0:rr26xx-5.0.ko

for FreeBSD 5.1-RELEASE
ok load disk0:rr26xx-5.1.ko

for FreeBSD 5.2.1-RELEASE
```

```
ok load disk0:rr26xx-5.2.1.ko

for FreeBSD 5.3-RELEASE
ok load disk0:rr26xx-5.3.ko

for FreeBSD 5.3-AMD64-RELEASE
ok load disk0:rr26xx-5.3-amd64.ko

for FreeBSD 5.4-RELEASE
ok load disk0:rr26xx-5.4.ko

for FreeBSD 5.4-AMD64-RELEASE
ok load disk0:rr26xx-5.4-amd64.ko

for FreeBSD 5.5-RELEASE
ok load disk0:rr26xx-5.5.ko

for FreeBSD 5.5-AMD64-RELEASE
ok load disk0:rr26xx-5.5-amd64.ko

for FreeBSD 6.0-RELEASE
ok load disk0:rr26xx-6.0.ko

for FreeBSD 6.0-AMD64-RELEASE
ok load disk0:rr26xx-6.0-amd64.ko

for FreeBSD 6.1-RELEASE
ok load disk0:rr26xx-6.1.ko

for FreeBSD 6.1-AMD64-RELEASE
ok load disk0:rr26xx-6.1-amd64.ko

for FreeBSD 6.2-RELEASE
ok load disk0:rr26xx-6.2.ko

for FreeBSD 6.2-AMD64-RELEASE
ok load disk0:rr26xx-6.2-amd64.ko

for FreeBSD 6.3-RELEASE
ok load disk0:rr26xx-6.3.ko

for FreeBSD 6.3-AMD64-RELEASE
ok load disk0:rr26xx-6.3-amd64.ko

for FreeBSD 7.0-RELEASE
ok load disk0:rr26xx-7.0.ko

for FreeBSD 7.0-AMD64-RELEASE
ok load disk0:rr26xx-7.0-amd64.ko
```

- 5) After the driver has been loaded, remove the floppy diskette from the floppy drive.
- 6) Type in "boot" and continue the installation as normal. You can refer to FreeBSD installation guide.

```
ok boot
```

Note

On some systems with ACPI enabled, FreeBSD may not work. You can try to disable ACPI in system BIOS or type the command "**set hint.acpi.0.disabled="1"**" under boot prompt to solve the problem.

- 7) Before exit install, an additional step must be taken to copy RR26xx driver module to system. On the driver disk, there is a setup script "**postinstall**" which will do this

work for you. Before you reboot the system, press **Alt-F4** to the command shell and type the following commands:

For common ISA floppy controller:

```
# mount -o ro /dev/fd0 /mnt
```

For USB floppy controller, we assume it is da0

```
# mount -o ro /dev/da0 /mnt
```

Then run script to do postinstall

```
# sh /mnt/postinstall
```

```
# umount /mnt
```

Then press **Alt-F1** to return to the setup screen and choose **[X Exit Install]** to finish setup.

Note: On some systems the floppy may be inaccessible during installation. In this case, please remove the CD, reboot from the installed system and load the driver manually from floppy again when booting from controller. After system boots up you can run the postinstall script to install the driver.

3 Installing RR26xx Driver on an Existing System

If you are currently running FreeBSD and would like to access drives or arrays attached to the RR26xx Controller, you can perform the following steps.

Step 1 Copy the Driver Module

If you have made freebsd drivers into a diskette, you can insert the driver diskette to floppy drive, then using the following commands to copy the driver module:

```
for FreeBSD 4.x:
# mount -o ro /dev/fd0 /mnt
# cp /mnt/rr26xx-xxx.ko /modules/rr26xx.ko
# umount /mnt

for FreeBSD 5.x/6.x/7.x:
# mount -o ro /dev/fd0 /mnt
# cp /mnt/rr26xx-xxx.ko /boot/kernel/rr26xx.ko
# umount /mnt
```

You can also extract the files from .img files directly, without using a floppy diskette:

```
For FreeBSD 4.x:
# vnconfig vn0c rr26xx-7.0.img
# mount /dev/vn0c /mnt
# cp /mnt/rr26xx-xxx.ko /modules/rr26xx.ko
# vnconfig -du vn0c myfilesystem mount=/mnt

For FreeBSD 5.x/6.x/7.x:
# mdconfig -a -t vnode -f rr26xx-7.0.img -u 0
# mount /dev/md0 /mnt
# cp /mnt/rr26xx-xxx.ko /boot/kernel/rr26xx.ko
# umount /mnt
# mdconfig -d -u md0
```

Step 2 Test the Driver Module

You can test out the module to ensure that it works for your system by load it during system booting.

If the module has been loaded successfully you should see the RR26xx banner and a display screen of the attached drives. You can now access the drives as a SCSI device (if you have no other SCSI device, the first device is /dev/da0, then /dev/da1, etc.).

Example

```
F1      FreeBSD
Default: F1

>> FreeBSD/i386 BOOT
Default: 0:ad(0,a)/boot/loader
boot:

BTX loader 1.00  BTX version is 1.01
Console: internal video/keyboard
BIOS driver A: is disk0
BIOS driver C: is disk2
BIOS 636kB/74512kB available memory

FreeBSD/i386 bootstrap loader, Revision 0.8
(mailto:jkhnarf.osd.bsdi.com, Sat Apr 21 08:46:19 GMT 2001)
Loading /boot/defaults/loader.conf
/kernel text=0x24f1db data=0x3007ec+0x2062c -
<- For FreeBSD 5.1 and later: select "6" on "Welcome to FreeBSD" screen.

Hit [Enter] to boot immediately, or any other key for command prompt.
Booting [kernel] in 9 seconds...

<-press SPACE key
Type '?' for a list of commands, 'help' for more detailed help.
ok load rr26xx
/modules/rr26xx.ko text=0xf571 data=0x2c8+0x254
ok autoboot
```

If you have configured a RAID 1/0 using 4 disks, it will be registered to system as device **/dev/da0**. You can use “/stand/sysinstall” to create partitions and disklabels (*like da0s1e*) on **da0**. Then you can create new filesystem using “**newfs /dev/da0s1e**”. Now you can mount **/dev/da0s1e** to somewhere to access it.

Step 3 Configure System to Automatically Load the Driver

Most likely, you will not want to type “load rr26xx” each time you boot up the system. Therefore you must install the module and tell the system about it. To configure system to automatically load the driver, type in the following commands:

```
# echo 'rr26xx_load="YES"' >> /boot/defaults/loader.conf
```

This tells the loader to try loading the RR26xx module together with the kernel.

Now, reboot the system. RR26xx module should be automatically loaded each time system start up.

Note

If FreeBSD you installed is 4.x version, you should type the following command to

configure your system:

```
# mknod /dev/rr26xx c 200 0
```

Then, please check whether node “**/dev/rr26xx**” exists in /dev directory.

Step 4 Configure System to Mount Volumes when Startup

Now you can inform the system to automatically mount the array by modifying the file /etc/fstab. E.g. You can add the following line to tell the system to mount /dev/da1s1e to location /mnt/hpt after startup:

```
/dev/da1s1e    /mnt/hpt      ufs    rw    0    0
```

4 Updating the Driver

To update the driver with a new version you simply reinstall the driver following the previous section, “Install the driver on an existing system”.

5 Installing RAID Management Software

HighPoint RAID Management Software is used to configure and keep track of your hard disks and RAID arrays attached to RR26xx controller. Installation of the management software is optional but recommended.

To configure HighPoint RAID Management Software to work with RR26xx driver, you should setup /etc/hptcfg to be the driver name:

```
# echo rr26xx > /etc/hptcfg
```

Please refer to HighPoint RAID Management Software documents for more information.

6 Uninstalling

You can only uninstall the driver when your system is not booting from devices attached to RR26xx controller. Just remove the line

```
rr26xx_load="YES"
```

in /boot/defaults/loader.conf, and then delete the driver module **/modules/rr26xx.ko** or **/boot/kernel/rr26xx.ko** .